



Thank you for purchasing Candoopro! Please read the following information before using the system for the first time. If you have any questions about the use of the system, please contact us at Sales@candoopro.com, or visit our Forum at <http://forums.candoopro.com/>.

Quick Start Guide – Ski Doo Snowmobiles

Hardware and Harness Guide; what's included:

The Candoopro system setup for Ski Doo Snowmobiles includes the following parts:

The Vehicle Diagnostic System Box, which connects to your PC and the sled:



The USB Cable, which connects the Vehicle Diagnostic System Box to the PC:




The 9-pin/6-pin adapter cable, which connects to the Vehicle Diagnostic System Box and to the various other adapter harnesses going to the ski:



The DESS adapter, which connects to the 9-pin/6-pin adapter, and connects to the DESS post. NOTE: This connection method is only used for early (1998-2002) models with carburetors. Do not use this adapter for later model PowerTek or fuel injected (SDI or E-Tec) skis .



The Ski Doo Main Power Adapter Harness, which is used on most later (2003+) models. This harness has two functions; 1. Applies power to the vehicle computer to enable communication. 2. Provides the connection between the vehicle and Candoopro.



The 9-Volt Adapter Cable, which is used on most early models (1998-2002) to provide power directly to the vehicle computer (MPEM), and used on later (2003+) carburetor models with the 6-pin diagnostic plug and the Main Power Adapter Harness.



The 12-Volt Adapter Cable, which is used on most later models (2003+) that have the 6-pin diagnostic plug. The 12-volt adapter cable plugs into the Main Power Adapter Harness, which is then plugged into the 6-pin diagnostic port on the vehicle.




Getting Started- Loading Software and Starting up the Program:

First Time: (Internet Connection is REQUIRED)

- Install USB Drivers, by entering the following into your web browser
 - <http://www.candopro.com/candoinstall/driver/usbdriver.exe>
- Connect CANDoo Professional System to the PC with the provided USB Cable
- Install CANDoo Professional Software, by entering the following into your web browser
 - <http://www.candopro.com/candoinstall/CanDooPro.msi>
- Start CANDoo Professional by going to start menu and launching CANDoo Professional
 - When prompted to download the new update, you must select "YES"

Each Use: (Internet Connection is Optional)

- Connect CANDoo Professional System to the PC with the provided USB Cable
- Start CANDoo Professional by going to start menu and launching CANDoo Professional
- Bottom left of the CANDoo Professional software shows the current status



-
- After vehicle is connected, select Vehicle menu option and click read

Vehicle Connection:

NOTE: Before connecting to a ski, please read the service manual for the particular model of snowmobile! There are a huge number of different models over the years, and there are many confusing differences between the various models.

Here are some general pointers for connecting to Ski Doo Snowmobiles.

- Most of the variation in connections (particularly power) was on 1998 to 2002 carbureted models.
- The vehicle computer (MPEM on early sleds, ECU or ECM on later sleds) needs power going to it to enable Candopro to communicate to it. There are two ways this can be accomplished. One way is to apply power to the computer, using the adapter cables. The other is to start the sled. (when the sled

is running, the computer is naturally powered up, either by the magneto on early sleds, or the battery/charging system and relay on later models). Most technicians prefer to apply power to the vehicle computer while the sled is not running.

- On most early sleds, the external power is applied by using the 9-volt Adapter Cable, plugged directly into the MPEM. (A very small number of sleds need special adapters, included in the kits for the appropriate years. Refer to service manuals for these applications)
- In 2003, BRP simplified connecting to Ski Doos, by putting a 6-pin diagnostic connector on the right side of the sled on most models (most carbureted models, and all fuel injected models)
- On these later sleds, the external power is applied by plugging the Main Power Adapter harness into the 6-pin diagnostic connector on the sled. The 12 Volt adapter cable or 9-volt adapter cable is then plugged into the matching connector on the Main Power Adapter to apply external power. (refer to the service manual for the appropriate power) If the sled has a battery, and is electric start, most operations for diagnostics and programming keys, etc, can be done without applying external power as the harness acts as a jumper for powering up the sled.
- If the Main Power Adapter Harness is used, you do not need to apply external power to the ski while the ski is running.

Typical Connections: (refer to Service Manual for the model you are working on for exact details)

Early (1998-2002) Carbureted models

- Connect the USB cable to the PC and the Candoopro Vehicle Diagnostic System box, and startup Candoopro application.
- Connect the 9-pin/6-pin adapter cable to the Candoopro Vehicle Diagnostic System box.
- Connect the DESS Adapter Cable to the 9-pin/6-pin adapter cable.
- Look at the MPEM; if it has a triangular-shaped connector with 3-pins on one end, disconnect this connector from the MPEM, and plug the 9-Volt adapter cable into the MPEM. Attach a fresh 9-volt battery to the 9-volt Adapter cable.
- If the MPEM does not have the triangular shaped connector, then you should simply start the sled and run it at idle.
- Remove the DESS tether from the post, and grasp the aluminum end of the DESS adapter cable, and slide it onto the DESS post of the sled.
- View the CANdoopro application; the small vehicle icon should turn green, and "DESS Detected" should appear on the lower bar.

- In the Vehicle Tab, select “Read Vehicle”
- Once the information is read, you are ready to start your diagnosis and change settings.
- When you make changes, you must write the changes to the sled with the “Write Vehicle” command in the Vehicle tab

Late models (2003+) with 6-pin Diagnostic connector

- Connect the USB cable to the PC and the Candoopro Vehicle Diagnostic System box, and startup Candoopro application.
- Connect the 9-pin/6-pin adapter cable to the Candoopro Vehicle Diagnostic System box.
- Locate the 6-pin Diagnostic port connector. It is typically on the right side of the sled in front. It is inserted into a protective cover, facing down. You need to pull it out of this protective cover by pushing the tab inward and pulling it out, usually upward. On some sleds, this connector is very difficult to remove as other harnesses are in the way. You may need to cut a tie-wrap of an adjacent harness to get clearance to disconnect the connector.
- Connect the Main Power Adapter Harness to the 6-pin diagnostic port connector.
- Connect the 6-pin end of the 9-pin/6-pin cable from the Candoo box to the mating 6-pin end of the Main Power Adapter Harness.
- View the CANdoopro application; if the the small vehicle icon should turns green, and “CAN Detected” appears on the lower bar, then you are ready to start a diagnostic session.
- If the vehicle indicator stays red, then you will need to apply external power. If the sled is a carbureted engine sled, then use the 9-volt adapter cable with a fresh battery. If the sled is fuel injected, or PowerTEK, use the 12-Volt adapter cable, and attach the clips to the vehicle battery or an external battery. NOTE: be sure to attach the RED clip to the Positive + terminal of the battery, and the BLACK clip to the Negative – terminal! Reversing these will cause damage!
- You should now see the vehicle icon turn green and be ready to start the session.
- Note: if the vehicle is a later fuel injected model, in order to use the Activate features, you must have external power applied with the 12 Volt Cable.
- In the Vehicle Tab, select “Read Vehicle”
- Once the information is read, you are ready to start your diagnosis and change settings.
- When you make changes, you must write the changes to the sled with the “Write Vehicle” command in the Vehicle tab. Note that with the SDI models, you must remove the DESS key from the post to finish the writing operation. Candoopro will prompt you for this.

Faq's:

- CANDoo Professional checks for updates on startup, if there is an active internet connection.
- If you are using wireless and get out of range, it can cause CANDoo Professional to freeze up while trying to connect to the website on startup. We suggest disabling the wireless on your laptop if you are moving out of wireless range.
- Make sure you have a fully charged battery, failure to do so can cause data corruption!